

Solid Wood & Engineered Flooring

Where are you laying the floor? and do you have under floor heating?

Under Floor Heating & Conservatory

Lounge – Bedroom – Kitchen – Utility – Dining Room

High Humidity - Bathroom – Below Ground Level

14 mm Engineered

22mm Engineered

Solid Wood

See Lagune under laminate

No acclimatisation required

Acclimitise for 3 to 7 Days

Moisture content of slab must be under 4%

Moisture content of slab must be under 4%

Now show the FULL range of products available

Fix

Float using Elka Grip over underlay with built in DPM

Full Adhesion – Elka Rigid or Elka Trowel Flex
Batten - Elka Trade Flex
Secret Nail 45 – 55mm Nails
Screw Elka Tongue Tite

Finish

3in 1 door bar

Maintain

Maintenance

Brushed and oiled

Lacquered

Elka Protect

Elka Clean

Elka Protect +

Please Note

The building should be fully enclosed including doors and windows.

Heating should be operational.

All wet work must have been completed otherwise the moisture will transfer from walls floors and ceilings to the hardwood flooring.

The delivered flooring must be left in the packaging with polythene wrapping intact.

The flooring should be stacked horizontally no more than 2 to 3 packs high or wide. Break up stacked cartons with battens to increase air circulation.

The use of gas or paraffin heaters should be avoided.

Do not store next to radiators.

Further checks must be undertaken by the installer to confirm the solid wood flooring is in equilibrium with the site it to be installed.

Subfloor must be level within 3mm over a 3m running area

WET MAINTENANCE IS ENTIRELY FORBIDDEN!