


# Laminate Flooring

**Where are you laying the floor? And do you have under floor heating?**



**Please Note**

- The building should be fully enclosed including doors and windows.
- Heating should be operational.
- All wet work must have been completed otherwise the moisture will transfer from walls floors and ceilings to the Laminate flooring.
- The screed / concrete subfloor should be tested with a none destructive Moisture metre
- Do not store next to radiators
- Checks must be undertaken by the installer to confirm the site is suitable to take the laminate flooring
- Each room must be individual and separated by a door profile ensuring 10mm expansion around the *FULL* perimeter of the room.
- Never run the floor over an area exceeding 10m
- The laminate should be run at a right angle to the floor boards

**WET MAINTENANCE IS ENTIRELY FORBIDDEN!**